

Liberty Suppressors

www.libertycans.net

Specification Sheet for Whitetail Integral Suppressor

Model name: Whitetail

Caliber: 6.5mm Creedmoor

Weight: 6lb. 8oz. Rifle/Suppressor Assembly
(Basically the same as the unsuppressed rifle!)

Length / Diameter: 14" x 1.375"

Materials: Titanium / 17-4 Stainless steel

Attachment: Integral Bolt Action Rifle Silencer

Ammunition Feed System: Detachable Magazine Fed

Description: This suppressor is specifically engineered for the hunter in mind. We wanted to build a silencer system that was convenient to use, but also accurate as well as quiet. Built on the proven Ruger bolt action rifle system, this combination provides an accurate, reliable and now **quiet** option for the hunter to choose. We chose the 6.5mm rifle round for it's inherent accuracy and reliability, this combination has proven to be a perfect match to our silencer module. Designed to keep the system light and maneuverable, we built the suppressor module to be only 2" longer than the original un-suppressed system. The design also has been developed to basically weight the exact same as the unmodified rifle. You wont even notice the silencer is there, until you need it...

To get yours, call us at 706-661-6911 or find us on the web at the address above!

LIBERTY SUPPRESSORS

113 GUNSMOKE TRAIL

TRENTON GA 30752

(706) 661-6911

WWW.LIBERTYCANS.NET

info@libertycans.net

Cleaning procedure the Whitetail integral

First clear the weapon, and verify that it's unloaded.

Next, unscrew the core from the end of the system. This can be done by using a $\frac{3}{8}$ " drive ratchet in the square pocket at the front of the core.

With the core unscrewed, remove the tube as well and clean both components. Leave the "brake" (it's really a gas diverter) on the barrel, as this part doesn't require service and it needs to stay attached. The back bushing / rear cap will stay captive on the barrel, but it can be cleaned in place if need be.

Lastly, reassemble. This is done in reverse order, by putting the tube back on, and threading the core back in. You can again use the $\frac{3}{8}$ " drive ratchet, but be sure not to over-torque it. Even just a few inches of leverage on that ratchet can increase the force significantly, so be sure it's just snug plus no more than a quarter turn.

Thank you for choosing Liberty Suppressors!

- **The Liberty Team**